

Instrucciones de montaje
 Installation Instructions
 Notice d'installation
 Istruzioni per il montaggio
 Montageanweisung
 Montagehandleiding

Montagevejledning
 Οδηγίες εγκατάστασης
 Instruções de montagem
 Monteringsanvisning
 Asennusohje
 Návod k montáži

Paigaldusjuhend
 Szerelési utasítás
 Montāžas instrukcija
 Montavimo instrukcija
 Instrukcja montażu
 Navodila za montažo

Návod na montáž
 Монтажни инструкции
 Instrucțiuni de montaj
 Инструкция по монтажу
 安装说明

IEC/EN 62208


Ac<=1000V In<125A

Dc<=1500V Fr<100Hz



IEC/EN 60674-24

Ac<=400V In<125A


Dc<=400V Fr<100Hz




	GHSE6PT	GHSP6PT	GHSE6PT/RR	GHSP6PT/RR	GHSE9PT	GHSP9PT	GHSE9PT/RR	GHSP9PT/RR	GHSE12PT	GHSP12PT	GHSE12PT/RR	GHSP12PT/RR	GHSE18PT	GHSP18PT	GHSE18PT/RR	GHSP18PT/RR	GHSEPC	GHSPPC
	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X
	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X	4X
	1X	1X	1X	1X	1X	1X	1X	1X	1X	1X	1X	1X	1X	1X	1X	1X	--	--
	1X	1X	1X	1X	1X	1X	1X	1X	1X	1X	1X	1X	1X	1X	1X	1X	--	--
	--	--	1X	1X	--	--	1X	1X	--	--	1X	1X	--	--	1X	1X	--	--
	2X	2X	2X	2X	2X	2X	2X	2X	2X	2X	2X	2X	2X	2X	2X	2X	2X	2X
	--	2X	--	2X	--	4X	--	4X	--	6X	--	6X	--	8X	--	8X	--	3x



GHSP-PC




GHSP-16C





GHSP-SKC




	X (mm)	X1 (mm)
GHSE6PT-/RR	22	3
GHSE9PT-/RR	57	13
GHSE12PT-/RR	70.5	34
GHSE18PT-/RR	86	32





GHSE12PT-/RR -- GHSE18PT-/RR
GHSP12PT-/RR -- GHSP18PT-/RR




TYPE / TIPO	N (mm ²)	PE (mm ²)
GHSE6PT-/RR GHSP6PT-/RR	4x(2.5-6mm ²)+2x(4-10mm ²)+	4x(2.5-6mm ²)+2x(4-10mm ²)+
GHSE9PT-/RR GHSP9PT-/RR	5x(2.5-6mm ²)+3x(4-10mm ²)+ 1x(16-35mm ²)	5x(2.5-6mm ²)+3x(4-10mm ²)+ 1x(16-35mm ²)
GHSE12PT-/RR GHSP12PT-/RR	6x(2.5-6mm ²)+6x(4-10mm ²)+ 1x(10-25mm ²)+1x(16-35mm ²)	6x(2.5-6mm ²)+6x(4-10mm ²)+ 1x(10-25mm ²)+1x(16-35mm ²)
GHSE18PT-/RR GHSP18PT-/RR	8x(2.5-6mm ²)+8x(4-10mm ²)+ 1x(10-25mm ²)+1x(16-35mm ²)	8x(2.5-6mm ²)+8x(4-10mm ²)+ 1x(10-25mm ²)+1x(16-35mm ²)



GHSE6PT/RR
GHSP6PT/RR
GHSE12PT/RR
GHSP12PT/RR
GHSE18PT/RR
GHSP18PT/RR
GHSE9PT/RR
GHSP9PT/RR
GHSEPC
GHSPPC



GHSE12PT/RR
GHSP12PT/RR
GHSE18PT/RR
GHSP18PT/RR







GHSE6PT-RR GHSP6PT-RR GHSEPC GHSPPC (PC)
-2xM20+1xM40
-2xM20+1xM40
-2xOB25

GHSE9PT-RR GHSP9PT-RR
-4xM20+1xM40
-4xM20+1xM40
-2xOB25

GHSE12PT-RR GHSP12PT-RR
-8xM20+2xM25+2xM32+1xM40
-4xM20+2xM25+2xM32+1xM40
-2xOB25_32_25

GHSE18PT-RR GHSP18PT-RR
-12xM20+6xM25+2xM32+1xM40
-10xM20+6xM25+2xM32+1xM40
-2xOB25_32_25





Instrucciones de montaje
Installation Instructions
Notice d'installation
Istruzioni per il montaggio
Montageanweisung
Montagehandleiding

Montagevejledning
Οδηγίες εγκατάστασης
Instruções de montagem
Monteringsanvisning
Asennusohje
Návod k montáži

Paigaldusjuhend
Szerelési utasítás
Montāžas instrukcija
Montavimo instrukcija
Instrukcja montażu
Navodila za montažo

Návod na montáž
Монтажни инструкции
Instrucțiuni de montaj
Инструкция по монтажу
安装说明

IEC/EN 62208



$Ac \leq 1000V$ $In < 125A$

$Dc \leq 1500V$ $Fr < 100Hz$


IEC/EN 60674-24

$Ac \leq 400V$ $In < 125A$




$Dc \leq 400V$ $Fr < 100Hz$








94273 - M25




GHNE-KA - M40







/






















+



94273 - M25

+





Instrucciones de montaje
 Installation Instructions
 Notice d'installation
 Istruzioni per il montaggio
 Montageanweisung
 Montagehandleiding

Montagevejledning
 Οδηγίες εγκατάστασης
 Instruções de montagem
 Monteringsanvisning
 Asennusohje
 Návod k montáži


Paigaldusjuhend
 Szerelési utasítás
 Montāžas instrukcija
 Montavimo instrukcija
 Instrukcja montażu
 Navodila za montažo

Νάvod na montáž
 Монтажни инструкции
 Instrucțiuni de montaj
 Инструкция по монтажу
 安装说明


IEC/EN 62208
 IEC/EN 60670-24

$A_c \leq 1000V$ $I_n < 125A$
 $A_c \leq 400V$ $I_n < 125A$


$D_c \leq 1500V$ $F_r < 100Hz$
 $D_c \leq 400V$ $F_r < 100Hz$




GHSP24PT-RR




GHSE24PT-RR




GHSP36PT-RR



GHSE36PT-RR



TYPE/mm	GHSP24PT GHSE24PT	GHSP36PT GHSE36PT
A	310	418
B	688	728
C	167	167
D	246	286
E	115	135
Ph	207	315
Pv1	121	145
Pv2	295	295




GHNE-KA
 M40-1x




94273
 M25-2x





GHSP-PC
 GHSP24PT=6x
 GHSP36PT=8x



GHSP-16C



GHSP-SKC



	X (mm)	X1 (mm)
GHSE24PT-/RR	70.5	34
GHSP24PT-/RR	70.5	34
GHSE36PT-/RR	86	32
GHSP36PT-/RR	86	32

